

SEARCH MODES



ALL-TERRAIN

Great for high-trash recreational areas, fields and historical locations including most general detecting.



GENERAL



FAST



CONDUCTORS
LOW



CONDUCTORS
HIGH



TRASH
REJECT



BEACH

Perfect for all salty conditions — dry sand, wet sand, surf and underwater.



GENERAL



CONDUCTORS
LOW



DEEP



SURF &
SEAWATER



GOLDFIELD

Ideal for gold nugget prospecting in mineralised goldfield locations.




GENERAL




Can't decide which Mode to use?
Use the General Mode for your detecting location.


QUICK START




1
TURN
ON



2
SELECT
SEARCH MODE



3
CANCEL
NOISE



4
GO
DETECTING



Scan the QR code or visit www.minelab.com/manticore for all product downloads including the full-length User Manual, specifications, software updates and learning resources.

Get these languages and more:

- EN English
- FR français
- PT Português
- DE Deutsch
- JP 日本語
- RU русский
- ES Español
- KO 한국어
- ZH 中文

For product compliance information:

Settings > General Settings > Compliance

minelab.com

4901-0315-1




MANTICORE

GETTING STARTED GUIDE



ASSEMBLY



TIGHTEN CAMLOCKS


Tighten the Camlocks if they slip or become loose.




Open



Tighten gently in increments




Close



Check and repeat if needed

CHARGING

7-8 HOURS




CAUTION: Charge your detector with a good-quality USB charger that has a minimum charging capacity of 2 A @ 5 V. Risk of USB charger failure if a low-quality charger is used.

Look for the following marks on USB chargers:



CAUTION: Only charge the detector in ambient temperatures between 0°C and +40°C.

3 HOURS



CONTROLS & DISPLAY



SETTINGS MENU

Press **▲** from the Detect Screen to open the Settings menu.



Back


- General Settings
- Frequency
- Audio Theme
- Target Tones
- Ferrous Tones
- Ferrous Limits
- Discrimination Pattern
- Recovery Speed
- Ground Balance
- Noise Cancel
- Search Mode
- Volume



- Flashlight
- Charge Status LED
- Large Metal Overload
- Search Mode
- Frequency
- Power
- Sensitivity Level
- Backlight/Lighting
- Action Bar
- Action Bar Soft Keys [x2]
- Sensitivity
- Pinpoint

- Tracking Ground Balance
- Wireless Audio
- Light Sensor
- Headphones Connectivity
- Battery Level/Charging
- Target ID Number
- Wireless Audio On/Off
- Target Depth Indicator
- Side Soft Key

ID MAP



Navigation Arrows [x4]